

Installation Instructions For Kewlmetal Helmet Locks: Page 1 of 1

READ COMPLETELY BEFORE BEGINNING INSTALLATION

Please check the website for revisions and updates.

- 1) First of all, these only fit the Kuryakyn ISO grips. If you already have the ISO grips, proceed to step 2, if not, install a pair of ISO grips per the Kuryakyn installation instructions.
- 2) Unscrew the 4 small allen screws that hold the grip end cap in place and remove the end cap and ring.
- 3) Place the ring in the groove at the base of the Kewlmetal Helmet Lock and fasten the lock to the end of the grip using the 4 screws you just removed. Rotate the lock so the slot is towards the bottom. Tighten the 4 screws and you are done!
- 4) Different helmets have different shaped D-rings. On some helmets you will have to rotate the D-ring so that it will reach far enough into the slot to be captured by the pin. If your D-ring is too small to reach, use the helmet extender provided.
- 5) We DO NOT recommend leaving the helmet extender in the helmet lock while riding.

Please check out our other products at: www.kewlmetal.com